



Standard Symbol

## BMP Objectives

- Soil Stabilization
- Sediment Control
- Tracking Control
- Wind Erosion Control
- Non-Storm Water Management
- Materials and Waste Management

**Definition and Purpose** Practices to remove tracked sediment to prevent the sediment from entering a storm drain or watercourse.

**Appropriate Applications** These practices are implemented anywhere sediment is tracked from the project site onto public or private paved roads, typically at points of ingress/egress.

**Limitations** Sweeping and vacuuming may not be effective when soil is wet or muddy.

- Standards and Specifications**
- Kick brooms or sweeper attachments shall not be used.
  - Inspect potential sediment tracking locations daily.
  - Visible sediment tracking shall be swept and/or vacuumed daily.
  - If not mixed with debris or trash, consider incorporating the removed sediment back into the project.

- Maintenance and Inspection**
- Inspect ingress/egress access points daily and sweep tracked sediment as needed, or as required by the Resident Engineer (RE).
  - Be careful not to sweep up any unknown substance or any object that may be potentially hazardous.
  - Adjust brooms frequently; maximize efficiency of sweeping operations.
  - After sweeping is finished, properly dispose of sweeper wastes at an approved dumpsite in conformance with the provisions in Standard Specifications Section 7-1.13 .